



How to Configure VPN on Android?

Configuration Steps

- 1. Using a computer to export VPN configuration file: Please refer the instructions below, choosing the configuration file you would like to export, click "Export" with the left mouse button and then the configuration file will be downloaded to your computer.
 - a. Export OpenVPN configuration file (Send All Traffic Over VPN Server): If the configuration file is added to your smart phone, then it will re-direct all internet traffic of your smart phone to BR-6208AC.
 - b. Export OpenVPN configuration file (The home-network access is allowed only over VPN server): If the configuration file is added to your smart phone, then your smart phone will be able to access to local LAN of BR-6208AC, and surf on the internet via router connected by smart phone or 3G/4G.






2. Send the VPN configuration file to the Email account on your smart phone.



3. Go to Google Play, search OpenVPN and download it.




4. After the OpenVPN is installed, check the email sent in Step 2. and click on Save as below.






5. Enable OpenVPN, click on Menu on the smart phone, and then choose Import.




6. Choose Import Profile from SD card.






7. Click on Download.




8. Choose VPN configuration file and then click on **Select**.





9. Enter the VPN User name and Password, then click on **Connect**. Choosing **Save**, you will not need to enter the User name and Password again once you disconnect and reconnect to the OpenVPN.



10. Once you connected, you will see the status **Connected** shown as below. Click **Disconnect** if you would like to terminate VPN connection.

