

## PS-1206MF MFP Printer Compatible list

No.	Brand Name	MFP Model	Windows 2000 & XP				Windows Vista 32/64				Remark
			Print	Scan	Fax	Card Reader	Print	Scan	Fax	Card Reader	
1	HP	CM1015MFP	✓	✓	N/A	N/A					
2	HP	Desk Jet 895cxi	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
3	HP	Desk Jet 970cxi	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
4	HP	Desk Jet D2460	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
5	HP	Desk Jet F2180	✓	--	N/A	N/A	✓	--	N/A	N/A	
6	HP	Desk Jet F380	✓	✓	N/A	N/A	✓	✓	N/A	N/A	
7	HP	Desk Jet F4185	✓	--	N/A	N/A	✓	--	N/A	N/A	
8	HP	Laser Jet 1010 (GDI)	✓	N/A	N/A	N/A					no Vista Driver
9	HP	Laser Jet 1018 (GDI)	✓	N/A	N/A	N/A	*✓	N/A	N/A	N/A	
10	HP	Laser Jet 1020 (GDI)	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
11	HP	Laser Jet 1022 (GDI)	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
12	HP	Laser Jet 3000dn	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
13	HP	Laser Jet 3015	✓	✓	✓	N/A					
14	HP	Laser Jet 3020	✓	--	N/A	N/A	✓	--	N/A	N/A	
15	HP	Laser Jet 3030	✓	✓	✓	N/A					
16	HP	Laser Jet 3050	✓	✓	--	N/A					
17	HP	Laser Jet 3052	✓	✓	N/A	N/A					
18	HP	Laser Jet 3055	✓	✓	--	N/A					
19	HP	Laser Jet 3380	✓	--	--	N/A					no Vista Driver
20	HP	Laser Jet 3390	✓	✓	--	N/A					
21	HP	Laser Jet 3392	✓	✓	--	N/A					
22	HP	Laser Jet M1005MFP	✓	✓	N/A	N/A	✓	✓	N/A	N/A	Vista 64 no scan function
23	HP	Laser Jet P1505	✓	N/A	N/A	N/A	*✓	N/A	N/A	N/A	
24	HP	PSC 750	✓	✓	N/A	N/A					
25	HP	PSC 1210	✓	✓	N/A	N/A	✓	--	N/A	N/A	
26	HP	PSC 1315	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
27	HP	PSC 1350	✓	✓	N/A	N/A					
28	HP	PSC 1410	✓	✓	N/A	N/A	✓	✓	N/A	N/A	
29	HP	PSC 1510	✓	✓	N/A	N/A	✓	--	N/A	N/A	
30	HP	PSC 1610	✓	✓	N/A	✓	✓	--	N/A	✓	
31	HP	PSC 2210	✓	✓	--	✓					
32	HP	PSC 2310	✓	✓	N/A	✓					
33	HP	PSC 2355	✓	✓	N/A	✓	✓	--	N/A	✓	
34	HP	PSC 2410	✓	✓	N/A	✓					
35	HP	PSC 2510	✓	✓	N/A	✓					
36	HP	Photosmart 2575	✓	✓	N/A	✓	✓	--	N/A	✓	
37	HP	Photosmart 2610	✓	✓	--	✓	✓	--	--	✓	
38	HP	Photosmart 2710	✓	✓	--	✓					
39	HP	Photosmart 3110	✓	✓	✓	✓					
40	HP	Photosmart 3310	✓	✓	--	✓					
41	HP	Photosmart 475	✓	N/A	N/A	✓					
42	HP	Photosmart 7450	✓	N/A	N/A	✓					
43	HP	Photosmart 7830	✓	N/A	N/A	✓					

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF MFP Printer Compatible list

No.	Brand Name	MFP Model	Windows 2000 & XP				Windows Vista 32/64				Remark
			Print	Scan	Fax	Card Reader	Print	Scan	Fax	Card Reader	
44	HP	Photosmart 8030	✓	N/A	N/A	✓	✓	N/A	N/A	✓	
45	HP	Photosmart 8230	✓	N/A	N/A	✓	✓	N/A	N/A	✓	
46	HP	Photosmart 8250	✓	N/A	N/A	✓					
47	HP	Photosmart 8450	✓	N/A	N/A	✓					
48	HP	Photosmart 8750	✓	N/A	N/A	--					
49	HP	Photosmart A526	✓	N/A	N/A	✓	✓	N/A	N/A	✓	no 2000 Driver
50	HP	Photosmart C3180	✓	✓	N/A	✓	✓	--	N/A	✓	
51	HP	Photosmart C4180	✓	✓	N/A	--					
52	HP	Photosmart C4280	✓	--	N/A	✓	✓	--	N/A	✓	
53	HP	Photosmart C4385	✓	--	N/A	✓	✓	--	N/A	✓	
54	HP	Photosmart C5180	✓	--	N/A	✓	✓	--	N/A	✓	
55	HP	Photosmart C5280	✓	--	N/A	✓	✓	--	N/A	✓	
56	HP	Photosmart C6180	✓	✓	N/A	✓	✓	--	N/A	✓	
57	HP	Photosmart C6280	✓	--	N/A	✓	✓	--	N/A	✓	
58	HP	Photosmart C7180	✓	--	--	✓	✓	--	--	✓	
59	HP	Photosmart C7280	✓	--	--	✓	✓	--	--	✓	
60	HP	Photosmart C8180	✓	✓	N/A	✓	✓	--	N/A	✓	
61	HP	Photosmart D5160	✓	N/A	N/A	✓	✓	N/A	N/A	✓	
62	HP	Photosmart D5360	✓	N/A	N/A	✓	✓	N/A	N/A	✓	
63	HP	Photosmart D7160	✓	N/A	N/A	--					
64	HP	Photosmart D7360	✓	N/A	N/A	✓	✓	N/A	N/A	✓	
65	HP	Office Jet 4255	✓	✓	--	N/A	✓	--	--	N/A	
66	HP	Office Jet 4355	✓	--	--	N/A	✓	--	--	N/A	
67	HP	Office Jet 5510	✓	✓	--	N/A					
68	HP	Office Jet 5610	✓	--	--	N/A	✓	--	--	N/A	
69	HP	Office Jet 6110	✓	✓	--	N/A					
70	HP	Office Jet 6210	✓	✓	--	N/A					
71	HP	Office Jet 6310	✓	--	--	✓	✓	--	--	✓	
72	HP	Office Jet 7130	✓	--	--	--					
73	HP	Office Jet 7210	✓	✓	--	✓					
74	HP	Office Jet 7410	✓	--	--	✓	✓	--	--	✓	
75	HP	Office Jet 9100	✓	✓	--	✓					
76	HP	Office Jet 9100	✓	✓	--	✓					
77	HP	Office Jet L7380	✓	--	--	N/A	✓	--	--	N/A	
78	HP	Office Jet L7580	✓	--	--	✓	✓	--	--	✓	
79	HP	Office Jet J5780	✓	--	--	N/A	✓	--	--	N/A	
80	HP	Office Jet K7100	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
81	HP	Office Jet K8600	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
82	HP	Office Jet Pro K5400dn	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
83	HP	Office Jet Pro K550	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
84	EPSON	CX1500	✓	✓	N/A	N/A					
85	EPSON	CX3700	✓	✓	N/A	N/A					
86	EPSON	CX3900	✓	✓	N/A	N/A	✓	✓	N/A	N/A	

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF MFP Printer Compatible list

No.	Brand Name	MFP Model	Windows 2000 & XP				Windows Vista 32/64				Remark
			Print	Scan	Fax	Card Reader	Print	Scan	Fax	Card Reader	
87	EPSON	CX3600	--	--	N/A	N/A	✓	✓	N/A	N/A	
88	EPSON	CX4100	✓	✓	N/A	N/A	✓	✓	N/A	N/A	
89	EPSON	CX4700	✓	✓	N/A	✓	✓	✓	N/A	✓	
90	EPSON	CX5500	✓	✓	N/A	N/A	✓	✓	N/A	N/A	
91	EPSON	CX5900	✓	✓	N/A	✓	✓	✓	N/A	✓	
92	EPSON	CX7300	✓	✓	N/A	✓	✓	✓	N/A	✓	
93	EPSON	CX8300	✓	✓	N/A	✓	✓	✓	N/A	✓	
94	EPSON	CX9300F	✓	✓	N/A	✓	✓	✓	N/A	✓	
95	EPSON	CX9400F	✓	✓	N/A	✓	✓	✓	N/A	✓	
96	EPSON	EPL-6200	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	no Vista 64 Driver
97	EPSON	EPL-5900L	✓	N/A	N/A	N/A	*✓	N/A	N/A	N/A	no Vista 64 Driver
98	EPSON	LQ-300+II	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	no Vista 64 Driver
99	EPSON	PHOTO 4990 Scanner	N/A	✓	N/A	N/A					
100	EPSON	R310	✓	N/A	N/A	--					
101	EPSON	R340	✓	N/A	N/A	✓					
102	EPSON	R350	✓	N/A	N/A	✓					
103	EPSON	RX430	✓	✓	N/A	✓					
104	EPSON	RX510	✓	✓	N/A	✓					
105	EPSON	RX520	✓	✓	N/A	✓	✓	✓	N/A	✓	
106	EPSON	RX530	✓	✓	N/A	✓	✓	✓	N/A	✓	
107	EPSON	RX560	--	--	N/A	--	✓	✓	N/A	--	UK model
108	EPSON	RX620	--	--	N/A	--	✓	✓	N/A	✓	UK model
109	EPSON	RX630	✓	✓	N/A	✓					
110	EPSON	RX650	✓	✓	N/A	✓	✓	✓	N/A	✓	
111	EPSON	RX700	--	--	N/A	--	✓	✓	N/A	--	UK model
112	EPSON	Stylus C110	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
113	EPSON	Stylus C45	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
114	EPSON	Stylus PHOTO1390	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
115	EPSON	Stylus PHOTO750	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
116	EPSON	Stylus PHOTO R270	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
117	EPSON	Stylus PHOTO R290	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
118	EPSON	Stylus PHOTO RX590	✓	✓	N/A	✓	✓	✓	N/A	✓	
119	EPSON	Stylus PHOTO RX640	--	--	N/A	--	✓	✓	N/A	✓	UK model
120	EPSON	Stylus DX4000	--	--	N/A	N/A	✓	✓	N/A	N/A	UK model
121	EPSON	Stylus DX4200	--	--	N/A	N/A	✓	✓	N/A	N/A	UK model
122	EPSON	Stylus DX4800	--	--	N/A	N/A	✓	✓	N/A	N/A	UK model
123	EPSON	Stylus DX5000	--	--	N/A	--	✓	--	N/A	--	UK model
124	EPSON	Stylus DX6000	--	--	N/A	--	✓	--	N/A	--	UK model
125	EPSON	Stylus DX7000F	--	--	--	--	✓	✓	--	--	UK model
126	EPSON	Stylus DX7400	--	--	N/A	--	✓	✓	N/A	--	UK model
127	EPSON	Stylus DX8400	--	--	N/A	--	✓	✓	N/A	--	UK model
128	EPSON	Stylus DX9400F	--	--	--	--	✓	✓	--	--	UK model
129	EPSON	Stylus PHOTO RX585	--	--	N/A	--	✓	✓	N/A	--	UK model

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF MFP Printer Compatible list

No.	Brand Name	MFP Model	Windows 2000 & XP				Windows Vista 32/64				Remark
			Print	Scan	Fax	Card Reader	Print	Scan	Fax	Card Reader	
130	EPSON	Stylus PHOTO RX650	✓	✓	N/A	✓	✓	✓	N/A	✓	
131	EPSON	Stylus PHOTO RX685	--	--	N/A	--	✓	✓	N/A	✓	UK model
132	EPSON	Stylus PHOTO RX690	✓	✓	N/A	✓	✓	✓	N/A	✓	
133	CANON	FAXPHONE L120	✓	N/A	--	N/A					
134	CANON	iP1200	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
135	CANON	iP1880	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
136	CANON	iP3300	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
137	CANON	iP3500	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
138	CANON	iP4300	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
139	CANON	iP4500	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
140	CANON	iX4000	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
141	CANON	PIXMA MP110	✓	✓	N/A	N/A					
142	CANON	PIXMA MP130	✓	--	N/A	✓	✓	--	N/A	✓	
143	CANON	PIXMA MP145	✓	✓	N/A	N/A	✓	✓	N/A	N/A	
144	CANON	PIXMA MP150	✓	✓	N/A	N/A					
145	CANON	PIXMA MP160	✓	✓	N/A	N/A					
146	CANON	PIXMA MP170	✓	✓	N/A	✓					
147	CANON	PIXMA MP180	✓	✓	N/A	--					
148	CANON	PIXMA MP450	✓	--	N/A	✓	✓	--	N/A	✓	
149	CANON	PIXMA MP510	✓	✓	N/A	--					
150	CANON	PIXMA MP520	✓	✓	N/A	✓	✓	✓	N/A	✓	
151	CANON	PIXMA MP530	✓	✓	--	N/A					
152	CANON	PIXMA MP700	✓	✓	--	✓					
153	CANON	PIXMA MP730	✓	✓	--	✓					
154	CANON	PIXMA MP810	✓	✓	N/A	--					
155	CANON	PIXMA MX7000	✓	✓	--	✓	✓	✓	--	✓	
156	CANON	Pro 9000	✓	N/A	N/A	N/A	✓	N/A	N/A	N/A	
157	LEXMARK	P4350	**✓	--	N/A	✓					no Vista Driver
158	LEXMARK	P6250	✓	--	N/A	--					
159	LEXMARK	X2350	✓	✓	N/A	N/A					
160	LEXMARK	X3330	✓	✓	N/A	N/A					
161	LEXMARK	X3350	✓	✓	N/A	N/A					
162	LEXMARK	X5150	✓	✓	N/A	N/A					
163	LEXMARK	X6150	✓	✓	✓	N/A					
164	LEXMARK	X6170	✓	✓	--	N/A	--	--	--	N/A	
165	LEXMARK	X7350	✓	✓	--	N/A	--	--	--	N/A	
166	LEXMARK	Z617 (GDI)	✓	N/A	N/A	N/A					
167	LEXMARK	Z735 (GDI)	✓	N/A	N/A	N/A					
168	Brother	MFC-210C	✓	✓	✓	✓					
169	Brother	MFC-215C	✓	✓	✓	✓					
170	Brother	MFC-2820	✓	N/A	✓	N/A					
171	Brother	MFC-420CN	✓	✓	✓	✓					
172	Brother	MFC-425CN	✓	✓	✓	✓					

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF MFP Printer Compatible list

No.	Brand Name	MFP Model	Windows 2000 & XP				Windows Vista 32/64				Remark
			Print	Scan	Fax	Card Reader	Print	Scan	Fax	Card Reader	
173	Brother	MFC-3240C	✓	✓	✓	N/A					
174	Brother	MFC-7420	✓	✓	✓	N/A					
175	Brother	MFC-7820N	✓	✓	✓	N/A					
176	Brother	MFC-8840D	✓	✓	✓	N/A					
177	Konica	2480MF	✓	✓	N/A	N/A	*✓	N/A	N/A	N/A	no Vista 64 Driver
178	Samsung	SF-565P	✓	✓	✓	N/A	✓	✓	✓	N/A	
179	Samsung	SCX-4100	✓	✓	N/A	N/A					
180	Samsung	SCX-4200	✓	✓	N/A	N/A					
181	Samsung	SCX-4521F	✓	--	✓	N/A	✓	--	✓	N/A	
182	Samsung	SCX-4720F	✓	✓	✓	N/A					
183	Samsung	SCX-5530FN	✓	✓	--	N/A					
184	Dell	944	✓	✓	N/A	✓					
185	Dell	MonoLaser MFP1125(GDI)	✓	--	✓	N/A	✓	--	✓	N/A	no 2000 Driver

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
1	HP	CLJ 1500L		
2	HP	CLJ 1600		
3	HP	CLJ 2550L	OK	
4	HP	CLJ 3500		
5	HP	CLJ 3500N		
6	HP	CLJ 3600		
7	HP	CLJ 3600n		
8	HP	CLJ 3600dn		
9	HP	CLJ 3700		
10	HP	CLJ 4600		
11	HP	CLJ CP3505	OK	
12	HP	LaserJet 2605		
13	HP	LaserJet 2700		
14	HP	LaserJet 4650		
15	HP	CM1015MFP		
16	HP	CM1017MFP		
17	HP	LaserJet 1010	N/A	
18	HP	LaserJet 1012		
19	HP	LaserJet 1015		
20	HP	LaserJet 1018	OK	No Vista 64
21	HP	LaserJet 1022(GDI)	OK	Note 1
22	HP	LaserJet 1200		
23	HP	LaserJet 1220		
24	HP	LaserJet 1300		
25	HP	LaserJet 1320		
26	HP	LaserJet 2300		
27	HP	LaserJet 2300L		
28	HP	LaserJet 2420		
29	HP	LaserJet 2420dn		
30	HP	LaserJet 3020	OK	
31	HP	LaserJet 4350		
32	HP	LaserJet 5200L		
33	HP	LaserJet 3015		
34	HP	LaserJet 3020		
35	HP	LaserJet 3030		
36	HP	LaserJet 3050		

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
37	HP	LaserJet 3050z	N/A	
38	HP	LaserJet 3052		
39	HP	LaserJet 3055		
40	HP	LaserJet 3200		
41	HP	LaserJet 3300		
42	HP	LaserJet 3330mfp		
43	HP	LaserJet 3380		
44	HP	LaserJet 3390		
45	HP	LaserJet 3392		
46	HP	LaserJet M1005MFP	OK	
47	HP	LaserJet P2015	OK	
48	HP	Deskjet 450		
49	HP	Deskjet 810C		
50	HP	Deskjet 880C		
51	HP	Deskjet 882C		
52	HP	Deskjet 920C		
53	HP	Deskjet 960		
54	HP	Deskjet 980		
55	HP	Deskjet 990		
56	HP	Deskjet 1120C		
57	HP	Deskjet 1180C		
58	HP	Deskjet 3325		
59	HP	Deskjet 3535		
60	HP	Deskjet 3550		
61	HP	Deskjet 3650		
62	HP	Deskjet 3820		
63	HP	Deskjet 3920		(Note1)
64	HP	Deskjet 5160		
65	HP	Deskjet 5440		
66	HP	Deskjet 5550		
67	HP	DeskJet 5652		
68	HP	DeskJet 5740		
69	HP	Deskjet 6122		
70	HP	DeskJet 6540		
71	HP	DeskJet 6840		
72	HP	Deskjet 9300		

“N/A” means the MFP doesn't support the function.

“ -- ” means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose “WinPrint” processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
73	HP	Deskjet 9650		
74	HP	Deskjet 995C		
75	HP	Deskjet D2360		
76	HP	Deskjet D2460	OK	
77	HP	Deskjet F2180	OK	
78	HP	Deskjet F380	OK	
79	HP	Business 1000		
80	HP	Business 1100d		
81	HP	Business 1200d		
82	HP	OfficeJet Pro K5300		
83	HP	OfficeJet Pro K5400		
84	HP	OfficeJet Pro K5400dn	OK	
85	HP	OfficeJet Pro K550	OK	
86	HP	OfficeJet Pro K850		
87	HP	OfficeJet Pro K850dtn		
88	HP	OfficeJet Pro L7380	OK	
89	HP	OfficeJet Pro J7580	OK	
90	HP	OfficeJet 4110		
91	HP	OfficeJet 4255	OK	
92	HP	OfficeJet 4355	OK	
93	HP	OfficeJet 5110		
94	HP	OfficeJet 5510		
95	HP	OfficeJet 5610	OK	
96	HP	OfficeJet 6110		
97	HP	OfficeJet 6210		
98	HP	OfficeJet 6310	OK	
99	HP	OfficeJet 7130		
100	HP	OfficeJet 7210		
101	HP	OfficeJet 7410	OK	
102	HP	OfficeJet 9100		
103	HP	OfficeJet 9110		
104	HP	OfficeJet 9120		
105	HP	OfficeJet 9130		
106	HP	OfficeJet J5780	OK	
107	HP	OfficeJet V40		
108	HP	Photosmart 145		

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
109	HP	Photosmart 245		
110	HP	Photosmart 325		
111	HP	Photosmart 375		
112	HP	Photosmart 475		
113	HP	Photosmart 2575	OK	
114	HP	Photosmart 2610	OK	
115	HP	Photosmart 2710		
116	HP	Photosmart 3110		
117	HP	Photosmart 3310		
118	HP	Photosmart 7260		
119	HP	Photosmart 7450		
120	HP	Photosmart 7550		
121	HP	Photosmart 7660		
122	HP	Photosmart 7760		
123	HP	Photosmart 7830		
124	HP	Photosmart 7960		
125	HP	Photosmart 8030	OK	
126	HP	Photosmart 8230	OK	
127	HP	Photosmart 8250		
128	HP	Photosmart 8450		
129	HP	Photosmart 8750		
130	HP	Photosmart A526	OK	
131	HP	Photosmart C3180	OK	
132	HP	Photosmart C4180		
133	HP	Photosmart C4280	OK	
134	HP	Photosmart C5180	OK	
135	HP	Photosmart C6180	OK	
136	HP	Photosmart C6280	OK	
137	HP	Photosmart C7180	OK	
138	HP	Photosmart C7280	OK	
139	HP	Photosmart D5160	OK	
140	HP	Photosmart D7160		
141	HP	Photosmart D7360	OK	
142	HP	PSC 750		
143	HP	PSC 1110		
144	HP	PSC 1210	OK	

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
145	HP	PSC 1315	OK	
146	HP	PSC 1350		
147	HP	PSC 1410	OK	
148	HP	PSC 1510	OK	
149	HP	PSC 1610	OK	
150	HP	PSC 2110		
151	HP	PSC 2210		
152	HP	PSC 2310		
153	HP	PSC 2355	OK	
154	HP	PSC 2410		
155	HP	PSC 2510		
156	HP	PSC 4110		
157	Canon	iC D380		
158	Canon	S200SPx		
159	Canon	C350		
160	Canon	i255		
161	Canon	i320		
162	Canon	i355		
163	Canon	i450		
164	Canon	i455		
165	Canon	i550		
166	Canon	i850		
167	Canon	i6100		
168	Canon	i6500		
169	Canon	i9100		
170	Canon	i9950D		
171	Canon	i475D		
172	Canon	i560		
173	Canon	i865		
174	Canon	iR 2010		
175	Canon	iP90		
176	Canon	iP1000		
177	Canon	iP1200	OK	
178	Canon	iP1500		
179	Canon	iP1880	OK	
180	Canon	iP2000		

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\*: Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
181	Canon	iP3000		
182	Canon	iP3300	OK	
183	Canon	iP3500	OK	
184	Canon	iP4000		
185	Canon	iP4200	OK	
186	Canon	iP4300	OK	
187	Canon	iP4500	OK	
188	Canon	iP5000	OK	
189	Canon	iP6000D		
190	Canon	iP8500D		
191	Canon	Pro 9000	OK	
192	Canon	iX4000	Ok	
193	Canon	iX5000		
194	Canon	PIXMA MP110		
195	Canon	PIXMA MP130	OK	
196	Canon	PIXMA MP145	OK	
197	Canon	PIXMA MP150		
198	Canon	PIXMA MP160		
199	Canon	PIXMA MP170		
200	Canon	PIXMA MP180		
201	Canon	PIXMA MP450	OK	
202	Canon	PIXMA MP510		
203	Canon	PIXMA MP700		
204	Canon	PIXMA MP730		
205	<b>SAMSUNG</b>	ML-1520LP		
206	<b>SAMSUNG</b>	ML-1740		
207	<b>SAMSUNG</b>	ML-2010		
208	SAMSUNG	SCX-4100		
209	SAMSUNG	SCX-4200		
210	<b>SAMSUNG</b>	SCX-4521F	OK	
211	<b>SAMSUNG</b>	SCX-4720F		
212	<b>SAMSUNG</b>	SF-565P	OK	
213	<b>Lexmark</b>	P4350		
214	<b>Lexmark</b>	Z1420	OK	
215	<b>Lexmark</b>	Z615		**
216	<b>Lexmark</b>	Z705		**

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
217	<b>Lexmark</b>	Z810		**
218	<b>Lexmark</b>	Z816		**
219	<b>Lexmark</b>	Z818	OK(Vista 32)	**No Vista 64
220	<b>Lexmark</b>	E120		
221	<b>Lexmark</b>	E230		
222	<b>Lexmark</b>	C510		
223	<b>Epson</b>	Aculaser C1100	OK	
224	<b>Epson</b>	Aculaser C1900		
225	<b>Epson</b>	Aculaser C4000		
226	<b>Epson</b>	Aculaser C4100		
227	<b>Epson</b>	Aculaser C8600		
228	<b>Epson</b>	DLQ-3500C		
229	<b>Epson</b>	EPL-6100		
230	<b>Epson</b>	EPL-6200	OK	No Vista64
231	<b>Epson</b>	EPL-N2500		
232	<b>Epson</b>	EPL-N3000		
233	<b>Epson</b>	LQ-300+II	OK	No Vista64
234	<b>Epson</b>	PictureMate PM210	OK	
235	<b>Epson</b>	Stylus C43UX		
236	<b>Epson</b>	Stylus C45	OK	
237	<b>Epson</b>	Stylus C63		
238	<b>Epson</b>	Stylus C67		
239	<b>Epson</b>	Stylus C83		
240	<b>Epson</b>	Stylus C90	OK	
241	<b>Epson</b>	Stylus C88		
242	<b>Epson</b>	Stylus C110	OK	
243	<b>Epson</b>	Stylus COLOR 740	OK	
244	<b>Epson</b>	Stylus COLOR 880		
245	<b>Epson</b>	Stylus COLOR 900		
246	<b>Epson</b>	Stylus COLOR 1160		
247	<b>Epson</b>	Stylus CX1500		
248	<b>Epson</b>	Stylus CX3100		
249	<b>Epson</b>	Stylus CX3700		
250	<b>Epson</b>	Stylus CX3900	OK	
251	<b>Epson</b>	Stylus CX4100	OK	
252	<b>Epson</b>	Stylus CX4700	OK	

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
253	<b>Epson</b>	Stylus CX5100		
254	<b>Epson</b>	Stylus CX5300		
255	<b>Epson</b>	Stylus CX5500	OK	
256	<b>Epson</b>	Stylus CX5700F		
257	<b>Epson</b>	Stylus CX5900	OK	
258	<b>Epson</b>	Stylus CX7300	OK	
259	<b>Epson</b>	Stylus CX8300	OK	
260	<b>Epson</b>	Stylus CX9300F	OK	
261	<b>Epson</b>	Stylus CX9400F	OK	
262	<b>Epson</b>	Stylus PHOTO 750	OK	
263	<b>Epson</b>	Stylus PHOTO 830U		
264	<b>Epson</b>	Stylus PHOTO 935		
265	<b>Epson</b>	Stylus PHOTO 1390	OK	
266	<b>Epson</b>	Stylus PHOTO 2100		
267	<b>Epson</b>	Stylus PHOTO R210		
268	<b>Epson</b>	Stylus PHOTO R230		
269	<b>Epson</b>	Stylus PHOTO R270	--	
270	<b>Epson</b>	Stylus PHOTO R310		
271	<b>Epson</b>	Stylus PHOTO R340		
272	<b>Epson</b>	Stylus PHOTO R350		
273	<b>Epson</b>	Stylus PHOTO RX430		
274	<b>Epson</b>	Stylus PHOTO RX510		
275	<b>Epson</b>	Stylus PHOTO RX520		
276	<b>Epson</b>	Stylus PHOTO RX530		
277	<b>Epson</b>	Stylus PHOTO RX630		
278	<b>Epson</b>	Stylus PHOTO RX650	OK	
279	<b>Brother</b>	HL-2070		
280	<b>Brother</b>	HL-5240		
281	<b>Brother</b>	MFC-210C		
282	<b>Brother</b>	MFC-215C		
283	<b>Brother</b>	MFC-2820		
284	<b>Brother</b>	MFC-3240C		
285	<b>Brother</b>	MFC-420CN		
286	<b>Brother</b>	MFC-425CN		
287	<b>Brother</b>	MFC-4800J		
288	<b>Brother</b>	MFC-7420		

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\* : Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.

## PS-1206MF USB Printer Compatible List

No.	Company	Printer Model	Windows Vista 32/64	Note
289	<b>Brother</b>	MFC-7820N		
290	<b>Brother</b>	MFC-8840D		
291	<b>Konica Minolta</b>	Magicolor 2480MF		
292	<b>Konica Minolta</b>	PagePro 1380MF		
293	<b>Dell</b>	944		
294	<b>Dell</b>	Mono Laser MFP 1125(GDI)	OK	No Win2K

"N/A" means the MFP doesn't support the function.

"--" means the function is not tested.

\*: Users have to close bi-directional.

\*\*: Some of Lexmarks, please close bi-directional, choose "WinPrint" processor and RAW printing.