

SKYMANAGE PC

Centralized Wireless
Network Management Software

Easy to Use. No License Fee.













Centralized & Remote Management

Windows Web-based SKYMANAGE PC wireless network management software for centralized remote configuration, control and monitoring the connected Edimax Pro access points and Wi-Fi clients across multiple sites with multi-tenant capability.



with Multi-Site Locations

Easy, Flexible & Scalable Configuration

Support up to 250 Edimax Pro CAP/WAP/IAP/OAP series access points and 10 sites with easy configuration wizard and access point auto-discovery utility for effectively and efficiently deploying fully functional wireless networks with flexibility and scalability.



Private-Cloud Virtual Controller

Easily accessible through any standard web browser, SKYMANAGE PC software is able to implement on virtual cloud server as a private-cloud*, allows the admin remotely access to manage the Wi-Fi networks and access points from anywhere, anytime.



Graphical Status, Reports, Tools

Intuitive interface supports graphical dashboard, zone plan and Google Maps for visual overviews of network setup, with easy drag-and-drop features to plan and simulate AP deployment to determine the best coverage areas for your APs.



Built for Businesses and Projects

SKYMANAGE PC is ideal for the demands of small-to-medium business environments including offices, hotels, schools, resorts, retailers, shopping malls, community, residential, etc., and system integrator projects.



No License Fee at Lower TCO

SKYMANAGE PC is free to use and no licensing cost. Total cost of ownership (TCO) of wireless network deployment with the SKYMANAGE PC impresses even the most cost-restricted organizations. Guaranteed to provide unmatched WLAN ROI (Return of Investment).



Rich features including traffic management, RF performance configuration, spectral analysis, AirTime Fairness, Band Steering, auto channel, captive portal, group setup, group configuration, group firmware upgrade, group restart, secure TLS Protocol and NAT traversal supported, single passcode and splash page for guest login.



* Need to be installed in cloud virtual server service such as AWS which is not included with the software.

Built for Business & Projects

Simplified Wireless Network Management for Businesses, Hospitality or Schools with Multi-Site Locations.

Easy to use and view real-time status and historical data with a dashboard overview web UI for the connected APs and clients across multiple sites. With rich features for effective and efficient performance, SKYMANAGE PC is ideal for the demands of small-to-medium business environments including offices, hotels, schools, resorts, retailers, shopping malls, community, residential, etc., and system integrator projects.



Hotel



SKYMANAGE PC

Zone Plan



Office



Google Maps



Dashboard







School

SKYMANAGE PC

Supported APs: Edimax Pro CAP, WAP, OAP & IAP series.

Ceiling-Mount & In-Wall Access Point



CAP1750

- AC1750 Dual-Band
- 1300Mbps (5GHz)



· PoE + Gigabit LAN x 1



CAP1300

- AC1300 Dual-Band
- 400Mbps (2.4GHz)+ 867Mbps (5GHz)
- PoE+ Gigabit LAN x 1, Gigabit LAN x 1
- 11ac Wave 2, MU-MINO



CAP1200

- AC1200 Dual-Band
- 300Mbps (2.4GHz)+ 867Mbps (5GHz)
- · PoE+ Gigabit LAN x 1





CAP300

- N300 Single-Band
- 300Mbps (2.4GHz)
- PoE+ Gigabit LAN x 1



IAP1200

- · N300 Single-Band
- 300Mbps (2.4GHz)
- PoE+ Gigabit LAN x 1, Gigabit LAN x 1, Phone Line In RJ11 x 1, Pohne Line Out RJ11 x 1



Wall-Mount & Outdoor Access Point



WAP1750

- AC1750 Dual-Band
- 450Mbps (2.4GHz)+ 1300Mbps (5GHz)
- PoE + Gigabit LAN x 1, PoE Out Gigabit LAN x 1



WAP1200

- AC1200 Dual-Band
- 300Mbps (2.4GHz)+ 867Mbps (5GHz)
- PoE+ Gigabit LAN x 1, Gigabit LAN x 1



OAP1750

- · AC1750 Dural-Band 450Mbps (2.4GHz)+ 1300Mbps (5GHz)
- PoE+ Gigabit LAN x 1



OAP1300

- · AC1300 Dural-Band
- 450Mbps (2.4GHz)+ 1300Mbps (5GHz)
- PoE+ Gigabit LAN x 1, PoE Out Gigabit LAN x 1

 11ac Wave 2, MU-MINO



CAP900

- · AC900 Single-Band
- 900Mbps (5GHz)
- PoE+ Gigabit LAN x 1, Passive PoE Out Gigabit IAN x 1

^{*}The SKYMANAGE PC software is free and provided "As Is" without warranty, service, or support. Please contact Edimax authorized distributor to download the software.

